

GENERAL USE GUIDE – LLELA GARMN ETREX 10

ACTIVATE [Both Off and On] – Holding down continuously will turn off unit


Press and hold the **LIGHT** button on the right side until the **START UP PAGE** appears.



The **GARMIN INFO** page appears and then defaults to the **MAIN MENU**.

If the **LIGHT** button is pushed after the **MAIN MENU** appears, info about the **GPS** is displayed.

GENERAL USE GUIDE – LLELA GARMN ETREX 10



DISPLAY

Time
Day
Date

Backlight Gauge
Pushing the LIGHT button changes light level

Battery Status
Indicates full but will decrease with use

Satellite Status
Left – weak
Right - strong



Screen will automatically revert to Main Menu after a few seconds.

MOVING AROUND [Refer

page 3 of Geocache Adventure Manual]

GENERAL USE GUIDE – LLELA GARMN ETREX 10

Left Side

ARROWS UP & DOWN

allow zoom in or out when maps are viewed.

MENU button

allows view of topics which go with current section



Upper Right Corner

BACK button

Allows user to move between current and previous selections

Note: Pushing this button will always return to the main menu screen.

THUMB STICK

[press in to select]

Used to move from icon to icon.

Access desired selection is done by pressing in on the thumb stick

SELECTING AN ICON.


Use the Thumb stick to move up / down / left or right.

The example above indicates the **MAP icon** is selected because it is highlighted in **dark blue**. This happens when moving around the icons. Each will be highlighted when that icon is touched.

The 6 icons displayed in the example above are considered the MAIN MENU. They may move around as the different icons are chosen but they do not disappear.

GENERAL USE GUIDE – LLELA GARMN ETREX 10

WHERE TO AND WAYPOINTS ICONS




THUMB STICK

Moving from **MAP** to **WHERE TO** icons is done by pushing to the right.

When **WHERE TO** is highlighted push in on the Thumb Stick to get to this menu

Waypoints are highlighted now push in again on the thumb stick to access pre-programmed waypoints

PLEASE DON'T ERASE THESE WAYPOINTS



PRE-PROGRAMMED WAY POINTS



WAYPOINTS MENU

Use **Thumb Stick** to move all the way down the page to **DONE** and press in again.

Waypoint list appears.

The **circle [O]** with **letter TRH** is the Trailhead symbol.

Flags are each waypoint on that trail.



GENERAL USE GUIDE – LLELA GARMN ETREX 10

PRE-PROGRAMED WAY POINTS [Continued]



WAYPOINTS MENU

Use **Thumb Stick** to move around the waypoints, push in to select.

Waypoints are highlighted in **DARK BLUE** when selected

The **circle [O]** with **TRH** letter is the Trailhead symbol.

Flags are each waypoint on that trail.




WAYPOINTS MENU

13 waypoints go with the Geocache Adventure Users manual. [Page 1]. All 13 are displayed in this guide.

The **FINAL #13** has a building symbol beside it.

PLEASE DON'T ERASE ANY OF THESE WAYPOINTS



GENERAL USE GUIDE – LLELA GARMN ETREX 10



Navigating to first Trail Head Cottonwood Trail.


Pressing the Back button will revert to the Main Menu

Press in on the Thumb Stick when 1 TRH COT is selected

Use the Up / Down arrows on left to zoom to 20 foot display on map.

Reading the screen 1 TRH is 5.7 miles in a North East direction away.

This a straight line not trail miles.




Using the pre-programmed waypoints is recommend to speed up your start time on the Geocache Adventure. [See Geocache Adventure Used Guide for more details]

There is much to learn about using a GPS, but this guide is designed to get you started with the basics first.

GENERAL USE GUIDE – LLELA GARMN ETREX 10

MANUALLY PROGRAMING COORDINATES

See Page 1 Table of Contents of the Geocache Adventure Users Guide



THUMB STICK


Move it to the right to select **Coordinates**

Coordinates will highlight in **Dark Blue**

Push in on the Thumb Stick to select **Coordinates**

Coordinates screen displayed below appears

Using this method will be more difficult than using the pre-programed Waypoints.




Moving around on the Coordinates screen is done by using up / down / left / right arrows.


The **North [N]** and **West [W]** longitude and latitude remain the same for all LLELA applications – Up / Down arrows to make change

Use the **left / right arrows** to move to the numbers to be changed then use the **thumb stick** to navigate to the number on the key pad to make the change.

After changes made **Thumb Stick** to **DONE** and press in




GENERAL USE GUIDE – LLELA GARMN ETREX 10



When **DONE** on the previous page is pressed a map is displayed. Left is on 120 mile view.

Use Up / Down arrows on left of GPS to zoom into the 20 ft. view on the right.

This a straight line not trail miles.



If you are a GPS beginner, using the pre-programed waypoints is recommend to speed up your start time on the Geocache Adventure. [See Geocache Adventure Used Guide for more details]

There is much to learn about using a GPS, but this guide is designed to get you started with the basics first.

If you have questions feel free to ask one of the LLELA Staff members or volunteers

We hope you enjoy this experience and will return as often as possible.